

1. Unpack the luminaire.




4. Tighten screws with tightening torque of 8 Nm.



7. Strip the end of the cable and pull it through a cable holder.



10. Connect the 2 core cable to the power supply (Class II.).



2. Prepare the luminaire for mounting on support rope. Loosen the screws on a bracket.




5. Connect the power supply gessis connector.



8. Connect the cable to the terminal block and tighten the holder. Close the luminaire.



11. Connect the 3 pin connector Gesis to the power supply (Class I.).



3. Hang the luminaire on a metal rope.




6. Cable connection.


Push the cable through the cable gland.




9. Connect the 3 core cable to the power supply (Class I.).




12. Connect the 2 pin connector Gesis to the power supply (Class II.).











- Recomended installation height up to 12 meters.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- The light sources in this luminaire is only replaceable by the manufacturer or their technicians or a qualified person.
- Caution, risk of electric shock




- Do not look directly or with optical aids into the light source RG1 d > 0,5 m  $\,$ 



- This luminaire operates at mains voltage 220-240V, 50-60 Hz.

Any modification to this luminaire is forbidden.

- Replace any cracked protective shield.



## Cleaning:

clean the luminaire with the standard detergents. DO NOT use any abrasive detergents or solvents.

## Instalation and maintainance:

can provide only a person with an electrical qualification.

ELEKTRO-LUMEN, s. r. o. Hranická 505

753 61 Hranice IV - Drahotuše Česká republika Telefon: +420 581 699 411 Fax: +420 581 699 419 E-mail: el-lumen@el-lumen.cz Web: www.el-lumen.cz And the state of t

The company reserves the right to change technical data and printing errors. Copyright © ELEKTRO-LUMEN, s. r. o.